

Product Data Sheet



PRATT & LAMBERT® PAINTS
Never compromise®

Accolade® Paint + Primer Interior Waterborne

- RZ4600/RF4600 Series – Flat**
- RZ4000/RF4000 Series – Velvet**
- RZ4700/RF4700 Series – Satin**
- RZ4100/RF4100 Series – Semi-Gloss**

Pratt & Lambert® Accolade® Interior Paint + Primer is a premium quality, 100% acrylic waterborne wall coating that provides an antimicrobial* coating, smooth application, outstanding hide, an easy-to-maintain stain and mar-resistant finish, and beautiful finished appearance. Accolade provides a mildew-resistant coating, making it ideal for high humidity areas such as a bathroom. It can be applied directly to most previously painted surfaces or uncoated drywall, plaster, masonry and non-bleeding wood without the use of a separate primer.

- Paint + Primer
- Smooth application
- Outstanding hide
- Easy-to-maintain finish
- Washable and scrubbable
- *Antimicrobial – This product contains agents which inhibit the growth of microbes on the surface of this paint film.

Recommended Uses

Recommended for use on walls, ceilings, trim, drywall, plaster, wood, masonry, metal and previously painted surfaces

Recommended Systems

SELF-PRIME the following substrates with 1 or 2 coats of Accolade® Interior Paint + Primer OR use the applicable primer as directed below:

Drywall:

- 1 coat Pratt & Lambert® Drywall Primer
- 1-2 coats Accolade® Paint + Primer Interior Waterborne

Masonry (cured 30+ days):

- 1 coat Pratt & Lambert® Multi-Purpose Waterborne Primer
- 1-2 coats Accolade® Paint + Primer Interior Waterborne

Concrete Block:

- For a filled effect use 1 coat Pro-Hide® Silver Latex Block Filler
- 1-2 coats Accolade® Paint + Primer Interior Waterborne

Plaster (cured 30+ days), Wood:

- 1 coat Pratt & Lambert® Multi-Purpose Waterborne Primer
- 1-2 coats Accolade® Paint + Primer Interior Waterborne

The following substrate requires the use of a primer:

Metal

- 1 coat Pratt & Lambert® Multi-Purpose Waterborne Primer
- 1-2 coats Accolade® Paint + Primer Interior Waterborne

10/14

Technical Data

Vehicle: 100% Acrylic

Finish:

Flat	0-5 units @ 85°
Velvet	20-30 units @ 85°
Satin	15-25 units @ 60°
Semi-Gloss	30-40 units @ 60°

Flash Point: N/A

Volume Solids*:

Flat	40 ± 2%
Velvet	35 ± 2%
Satin	36 ± 2%
Semi-Gloss	37 ± 2%

Weight Solids*:

Flat	55 ± 2%
Velvet	49 ± 2%
Satin	48 ± 2%
Semi-Gloss	50 ± 2%

Weight/Gallon*:

Flat	11.2 lbs.
Velvet	10.5 lbs.
Satin	10.3 lbs.
Semi-Gloss	10.4 lbs.

VOC:** VOC < 50 g/L – 0.42 lb/gal as per 40 CFR 59.406

**VOC for Semi-Gloss Designer White/Base and Base 1:
VOC: 139 g/L – 1.16 lb/gal as per 40 CFR 59.406.

Spread Rate: 400 sq. ft. per gallon

Film Thickness:

Flat	@ 4 mils wet; 1.6 mils dry
Velvet	@ 4 mils wet; 1.4 mils dry
Satin	@ 4 mils wet; 1.4 mils dry
Semi-Gloss	@ 4 mils wet; 1.5 mils dry

* Product data calculated on Base 1

Drying Time (@ 77°F, 50% R.H.):

Note: Drying times are temperature, humidity, and film thickness dependent.

To Touch: 30 minutes
To Recoat: 4 hours

Reduction: Water

Tinting: Universal colorants

Bases/Colors Per Finish:	Fl	Ve	Sa	S-G
Designer White Base	✓	✓	✓	✓
Red Base		✓		
Yellow Base		✓		
Base 1/White	✓	✓	✓	✓
Base 2	✓	✓	✓	✓
Base 3	✓	✓	✓	✓

Sizes: Quart, Gallon, 5 Gallon

As of 10/1/14, complies with:

	Fl	Ve	Sa	S-G
OTC	✓	✓	✓	✓
EC	✓	✓	✓	✓
SCAQMD	✓	✓	✓	**
CARB	✓	✓	✓	✓
LADCO	✓	✓	✓	✓
*MPI Spec #:				54

**Semi-Gloss Designer White/Base and Base 1/White are not SCAQMD compliant, but Base 2 and Base 3 are SCAQMD compliant.

*Please refer to the MPI Approved Products website for the most current list of approved Pratt & Lambert products.

<http://www.paintinfo.com/mpi/approved/index.shtml>

Product Data Sheet

Surface Preparation

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

To ensure proper adhesion, the surface to be painted must be free of dirt, dust, oil, grease, wax, rust, and any other surface contaminants. Clean surface using an appropriate cleaner. Rinse thoroughly and allow to dry. Sand or scrape surface to remove any loose paint and to smooth old surfaces. Dull glossy surfaces by using 150 grit sandpaper. Fill cracks and holes with spackling paste to smooth uneven areas. When dry, sand and remove sanding dust.

Drywall: Wipe with a damp cloth to remove dust. Allow to dry. Fill cracks & holes with spackling compound and sand smooth. Joint compound must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete Block: All new surfaces must be cured according to the supplier's recommendations—usually at least 30 days – and have a pH between 7 and 10. Remove all form release and curing agents, efflorescence, salts, laitance, and other foreign matter. Patch cracks and holes with an appropriate filler. Rough surfaces may be filled to provide a smooth surface.

Plaster: All new surfaces must be hard and cured according to the supplier's recommendations—usually at least 30 days. Treat textured, soft, porous, or powdery plaster with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with water and allow to dry.

Wood, Pre-Primed Fiberboard, Hardboard, Plywood: Sand any exposed wood to a fresh smooth surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Remove all sanding dust.

Aluminum and Galvanized Metal: Wash with appropriate cleaner to remove any oil, grease, or other surface contamination using a water-based cleaner-degreaser. Remove all corrosion with sandpaper, steel wool, or other abrading method.

Caulking: Fill gaps between walls, ceilings, crown moldings, and other trim with latex or siliconized latex caulk after priming the surface.

Mildew: Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the mildewed area for 10 minutes. Rinse thoroughly with water and allow surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of Pratt & Lambert Paints. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Pratt & Lambert dealer or representative to obtain the most recent Product Data Sheet.

Accolade® Paint + Primer Interior Waterborne
RZ4600/RF4600 Series – Flat
RZ4000/RF4000 Series – Velvet
RZ4700/RF4700 Series – Satin
RZ4100/RF4100 Series – Semi-Gloss

Application

Temperature (air, surface and material):

Apply at temperatures above 50°F

More than one coat of paint may be necessary for new and uncoated surfaces, dramatic color changes, or when using dark/vibrant colors for optimal appearance and hide.

Airless Spray:

Pressure.....	2000 psi
Tip.....	.015" - .019"
Reduction.....	Not necessary

Conventional Spray:

Air Pressure.....	40-60 psi
Fluid Pressure.....	20 psi
Tip.....	704/FX
Reduction.....	Up to 1 pint water/gallon

Brush:

Brush.....	Nylon/polyester
Reduction.....	Not recommended

Roller:

Cover.....	1/4" - 3/4" synthetic
Reduction.....	Not recommended

Tips to Improve Performance

- Clean the surface thoroughly
- Prepare the substrate to create a uniform surface
- Patch cracks, crevices, and through-wall openings using proper sealant or patch
- Fill voids and openings around windows and doors using proper sealant or patch
- Caulk as needed using quality latex or paintable siliconized latex caulk or sealant

Cautions

- **Protect from freezing**
- **For interior use only**
- **Non-photochemically reactive**

Clean Up

Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.